276,66

appareil ou déposer la batterie dans un point de collecte officiel pour son recyclage. Les batteries peuvent être jetées dans le cadre du ramassage des ordures ménagères si elles sont exposées à des températures élevées. Les autres de ces précautions peut provoquer un incendie et/ou des blessures graves. Pour plus d'informations sur le traitement, la récupération et le recyclage de ce produit, prière de contacter votre mairie, votre service d'élimination des déchets ménagers ou le magasin où vous avez acheté le produit.

SE DÉBARRASSER DE LA BATTERIE

Ce appareil contient une batterie Li-ion qui doit être retirée avant de jeter l'appareil usagé. Laisser fonctionner l'appareil jusqu'à ce que la batterie soit complètement vide. Désserrer et enlever les vis situées sur le côté de l'appareil. Ouvrir le boîtier. Retirer la batterie. Couper les câbles de connexion. Couper les câbles de connexion au cœur et retirer la batterie. Éliminer correctement la batterie (à un point de collecte, ou chez le revendeur). **⚠ AVERTISSEMENT:** Ne pas toucher les contacts ou les fils, pour éviter tout risque de court-circuit. **⚠ AVERTISSEMENT:** La pile peut explorer si elle est exposée à la lumière du soleil, à de la chaleur ou du feu. **⚠ AVERTISSEMENT:** L'ouverture de la batterie peut entraîner un risque de blessure dû à un court-circuit, des brûlures chimiques ou à la fuite de vapeurs irritantes.

GARANTIE

Garantie 2 ans

VOTRE ADRESSE DE CONTACT !

B : FHP Vileda S.C.S., Avenue André Ernst 14, 4800 Verviers, Belgique/België **F :** FHP Vileda S.A., 4 jw Laurent Cully, Hall D - 4e étage, 92600 Asnières sur seine
La présente garantie n'est valable que pour le nettoyeur vitre de Vileda. La garantie du nettoyeur vitre de Vileda est conforme à la directive 1999/44/CE. Vileda garantit que le nettoyeur vitre est sans défaut de ni matériau défectueux ou à la fabrication.Si des défauts apparaissent durant la période de garantie, Vileda s'engage à remplacer ou réparer gratuitement le nettoyeur vitre de Vileda. Les frais de port ne sont pas à charge. Cependant, Vileda se réserve le droit de refuser une partie ou une partie de notre offre d'utilisation, comme par exemple : 1. S'il a été atteint à cause d'une mauvaise utilisation ou d'un mauvais entretien. 2. Si une partie de l'appareil est modifiée ou remplacée ou si l'appareil est utilisé d'une façon non recommandée par Vileda. 3. Si l'appareil est utilisé avec une pièce non fabriquée ou recommandée par Vileda. 4. Si le nettoyeur vitre est utilisé à des fins commerciales. Si après avoir suivi cette notice d'utilisation vous êtes certain que votre produit est défectueux, appelez le service consommateur de Vileda. Soyez prêt avec le produit, une description complète du problème, votre preuve d'achat, votre nom, adresse et numéro de téléphone. Vileda ne prend pas la responsabilité pour un dommage secondaire ou indirect causé par une mauvaise utilisation du produit. La responsabilité de Vileda n'a pas au-delà du prix d'achat du produit. Si vous avez une doute sur la bonne utilisation du produit ou sur la présente garantie, appelez le Service Consommateur de Vileda. La garantie n'inclut pas les batteries.

NL/B

Dank u voor de aankoop van onze nieuwe Vileda raamreiniger Windo Matic. De Vileda raamreiniger Windo Matic, eenvoudig in gebruik, droogt uw ramiges zonder sporen, na het wassen van uw ramiges met uw favoriete schoonmaakmiddel, niet weer dé aan handdoogen met een trekker dat u degen het raam dust. Het zugt doeltreffend het water van uw ramiges weg. Dankzij de dubbele trekker zal geen druppel water op uw ramiges achterblijven. Geen sporen op de ventiers, geen druipsporen op uw ramen, winterbanden of kozijnen... Gemakkelijk!

Deze handleiding is een omnibase gids voor een correct en veilig gebruik van de Vileda windo matic. Lees daarom al deze instructies voordat u het product voor de eerste keer gebruikt en bewaar deze handleiding voor latere raadpleging.

INHOUD:

Algemene waarschuwingen • Samenstelling • Snelstart • Gebruik van het product • Reiniging van het toestel • De batterij laden en herladen • Indicatielampje • Problemen oplossen • Milieu en recyclage - Batterij verwijderen • Technische gegevens • Waarborgformule

⚠ BELANGRIJK:

Lees aandachtig alle instructies vóór gebruik. Bewaar deze instructies en waarschuwingen voor latere raadpleging.

GEZONDHEID EN VEILIGHEIDSWAARSCHUWINGEN:

Bij het gebruik van een elektrisch apparaat, moeten altijd elementaire veiligheidsmaatregelen worden genomen om het risico op brand, elektrische schokken, lekkende batterijen of personelle letsel te verminderen, waaronder de volgende: - Dompelt het apparaat noit in water of andere vloeistof - Steek geen voorwerpen in de ventilatie openingen - Dit toestel mag gebruikt worden door kinderen vanaf 14 jaar of door personen met een lichamelijke, mentale of zintuiglijke beperking, die onvoldoende ervaring of kennis hebben, tenzij ze onder toezicht staan of instructies krijgen in verband met het gebruik van het toestel van een persoon die verantwoordelijk is voor hun veiligheid. Kinderen mogen niet met het toestel spelen. Het toestel mag niet door kinderen worden gereinigd of onderhouden, tenzij ze ouder zijn dan 8 jaar en onder toezicht staan. - Het toestel mag alleen gebruikt worden in overeenkomst met de vermeldingen op het toestel. - Check voordat u de machine gaat gebruiken en na elke klap of er geen sporen van slijtage of beschadiging zijn. - Gebruik het toestel niet als er een onderdeel beschadigd of defect is - Gebruik enkel vervangonderdelen of accessories de door Vileda worden geleverd of aanbevolen. - Breng aan de lader of het toestel geen enkele wijziging aan. - Gebruik enkel de lader die met het toestel wordt meegeleverd. Probeer de lader niet te gebruiken op een ander toestel en probeer dit toestel niet op te laden met een andere lader. Het gebruik van een ongeschikte lader kan een risico van brand veroorzaken. - Ga voor gebruik na of het snoer van de lader geen sporen van beschadiging of slijtage vertoont. - Probeer noit een beschadigd snoer van de lader te vervangen. Als de voedingskabel van de lader beschadigd is, moet hij vervangen worden. - Trek de lader uit het stopcontact voor u het toestel gaat reinigen. - Houd de batterij uit de buurt van hete oppervlakken en scherpe randen. - Neem de lader of het toestel niet vast met natte handen. - Breng het toestel niet buiten op en laat het niet buiten op. - Voor meer informatie, technisch advies of om reserve-of vervangonderdelen te bestellen neem u contact met Vileda (www.vileda.com).

OPRUIMEN:

- Breng het toestel rechtop op - Breng het toestel op een droge plaats op - Breng het toestel op buiten het bereik van kinderen - Zorg ervoor dat het toestel niet aangesloten is als het opgeborgen is

HOE TE GEBRUIKEN:

I- In deze handleiding wordt beschreven waarvoor het toestel gebruikt dient te worden. Het gebruik van bestanderen of toegevoegde onderdelen, of het gebruik van dit toestel voor andere doeleinden dan deze die worden voorgeschreven in deze handleiding kunnen een risico op verwonding vormen. - Gebruik dit toestel uitsluitend voor het reinigen van ramiges en vochtige oppervlakken, zoals ventiers, keukenfronten en tegels. - Wij raden het gebruik van dit product op oppervlakken die gemakkelijk kunnen worden gekrast, zoals hout, staal, geblakte oppervlakken. - Gebruik dit apparaat alleen met traditionele reinigingsproducten voor ramen (zonder alcohol, geen detergent dat schuimt) - Gebruik het niet om brandbare, brandende of ontwelkende zaken te reinigen.

SNELSTART

Verwijder al het beschermkarton voordat u begint. Bij het uitpakken van het product, controleer of er geen accessoires ontbreken en geen enkel element van het product beschadigd is. Als u eventuele schade ontdekt, neem contact met de winkel waar u uw product gekocht heeft. Bewaring de zuigmond op het toestel totdat deze op zijn plaats wordt ingeklikt met een kwaliteit gebruik, (afbeelding **1**). Laad de batterij, vóór het eerste gebruik gebruikte gedurende 6 uur (afbeelding **2**) (Raadpleeg het hoofdstuk "De batterij laden en herladen" voor meer details). Als een volledige oplading van het toestel, bedraagt de gebruiksduur 20 minuten.

GEBRUIK VAN HET TOESTEL

Ze het reinigen van ramiges met uw gebruikelijk schoonmaakmiddel, werkt de Vileda Windo Matic als een handwoudum dat krachtig af het sulle water in zijn gaintegrerende waterreservoir zugt. Breng het reinigingsmiddel voor uw ramiges aan volgens de instructies van de fabrikant en reinig het oppervlak volgens de methode van uw keuze. (afbeelding **3**). Akrams het toestel te gebruiken, zorg ervoor dat de wissers niet vuil zijn. Schakel het toestel in (afbeelding **4**). Breng een zachte druk op het toestel aan om de wisser op het oppervlak te steunen. De zuiste hoek wordt automatisch aangepast dankzij de flexibele hals van het toestel. Gebruik het toestel op hgt gelijke oppervlak van boven naar beneden of horizontaal om het reinigen zo te zugen (afbeelding **5** en **6**). In geval van opzuigen van grote hoeveelheden vloeistof op horizontale oppervlakken, kan u het toestel ook ondersteboven zugen (dan wordt de zuigmond op de opzeeslak en beweeg het toestel over de vloeren). De moeilijk bereikbare plaatsen zijn toegankelijk dankzij de flexibele kop van het apparaat, zonder het contact van de uw de zuigkantjes op de opzeeslak te verlieren (afbeelding **7**).

HET WERK ONDERBREKEN

Schakel het toestel uit en zet het rieer op het voetstuk (parkeerstand) (afbeelding **8**).

REINIGING VAN HET TOESTEL

Het waterreservoir leegmaken

Zodra het maximale niveau (100 ml) van uw water wordt bereikt, zorg ervoor dat uw water reservoir leegmaken. Ze het waterreservoir leegmaken, verwijder de zuigmond door de knop van de zuigmond te drukken (afbeelding **9**). Verwijder vervolgens het stuk van de zuigmond van de zuigmond. Het waterreservoir, nu dat u de zuigmond op de zuigmond hebt verwijderd, kan u het waterreservoir, nu dat u hem hebt verwijderd, kan u de zuigmond op de zuigmond leegmaken. Bij de uitgang van de zuigmond van de zuigmond

1 Unit parts • 1 Inhalt • 1 Samenstelling • 1 Descripción del aparato

GB	DE	DK	NL	I
① main unit	① Hauptteinheit	① Unité centrale	① Hoofdtoestel	① Unidad principal
② squeegee	② Düse	② Embout	② Mondstuk	② Boquilla de aspiración
③ dirt water reservoir top	④ Wasserbehälter Oberteil	④ Rackets	③ Zuigmond	③ Labio de goma
④ dirt water reservoir bottom	⑤ Wasserbehälter Unterteil	③ Rand du réservoir d'eau sale	④ Top van het vuilwaterreservoir	④ Deposito de agua sucia superior
⑤ tube separator for dirt water reservoir	⑥ Trennvorrichtung für Wasserbehälter	⑤ Fond du réservoir d'eau sale	⑤ Onderkant van het vuilwaterreservoir	⑤ Deposito de agua sucia inferior
⑥ unlocking button	⑦ Entriegelungsknopf	⑥ Tube séparateur pour le réservoir d'eau sale	⑥ Buis afscheider voor het vuilwaterreservoir	⑥ Tubo separador para el deposito de agua sucia
⑦ ON/OFF switch for appliance	⑧ Ein/Aus-Schalter	⑦ Bouton de déverrouillage	⑦ Ontgrendelingsknop	⑦ Botón desbloqueo
⑧ Charge/Operations display	⑨ Ladeanzeige	⑧ Interrupteur ON/OFF de l'appareil	⑧ ON/OFF-schakelaar voor het apparaat	⑧ Interruptor ON/OFF del aparato
⑨ charger socket	⑩ Ladebuchse	⑨ Affichage de charge / fonctionnement	⑨ Laadindicatie / bediening	⑨ Indicador de carga/funcionamiento
⑩ charger with charging cable	⑪ Ladegerät mit Ladekabel	⑩ Prise de chargement	⑩ Batterijaansluiting	⑩ Enchufe
		⑪ Chargeur avec câble de chargement	⑪ Lader met oplaadkabel	⑪ Cargador con cable

Cleaning Main Unit

1. After use, switch the appliance off and remove the charger. The appliance can be cleaned or wiped with a damp cloth. Do not use abrasives, solvents or polishes to clean the outside of the unit. ⚠ **WARNING:** the base, appliance contains electrical components. Never immerse the unit in water, do not rinse the appliance under the tap or washing machine and do not clean under running water! Store appliance on the pedestal in an upright position. Store appliance in a dry place. For further help, technical advice, or to order spare or replacement parts please contact Vileda Customer Service (www.vileda.com).

BATTERY CHARGING & RECHARGING

Charge rechargeable for 6 hours before first use. Switch off the unit before charging. Connect the supplied battery charger into the charging socket located below the power buttons. Plug the charger into a suitable electrical socket. The charge/operations display will turn RED when the charger is connected and the battery is charging. The light indicator will turn GREEN after charging is complete. Unplug the charger from the socket and the charger socket. ⚠ **WARNING:** Do not touch contacts or wires, to prevent risk of short circuit. Do not attempt to force to fully recharge the battery pack after the unit is automatically stopped due to low battery power. If the appliance is connected to the charger while it is on, the motor will stop immediately and the battery will start charging. ⚠ **WARNING:** DO NOT USE THE CHARGER WHEN THE CHARGING PORT IS WET IN THE PRODUCT. DO NOT ATTEMPT TO USE THE CHARGER WITH ANY OTHER PRODUCT. NOR ATTEMPT TO CHARGE THE PRODUCT WITH ANOTHER CHARGER. DO NOT DISASSEMBLE THE PRODUCT AND THE BATTERY, AND THEN INVALIDATE YOUR GUARANTEE. ⚠ **WARNING:** To maintain peak performance of the battery it is recommended that the unit is fully discharged and then completely recharged at least once a month.

LIGHT INDICATOR

NO LIGHT (motor running):	Appliance is operating normally
SLOW BLINKING RED (motor running):	Weak battery (equal to less than 20% capacity)
SOLID RED (motor stopped):	Battery is flat
FAST BLINKING RED (motor stopped):	Thermal cut-off activate (e.g. Vent is blocked)
SOLID RED (white charging):	Battery is charging
SOLID GREEN (white charging):	Battery is fully charged
FAST BLINKING RED (white charging):	Detection of damaged battery during charging
SLOW BLINKING RED (white charging):	Detection of wrong charger being plugged in

TROUBLESHOOTING

Problem	Possible reason	Possible solution
Poor cleaning and liquid pick up	• Squeegee is soiled • Nozzle is not completely in contact with surface	• Clean squeegee with a wet cloth. Replace squeegee if necessary. • Ensure the nozzle and the nozzle are connected
Water is leaking from the water reservoir	• The max. fill level (100 ml) mark) of the dirt water reservoir is exceeded. • Appliance is being held upside down.	• Empty the dirt water reservoir. • Turn appliance in its upright position.
Cleaning time too short	• Battery flat	• Recharge battery for 6 hours
Unit fails to operate	• Battery flat • Battery is damaged or mechanical defect	• Recharge battery for 6 hours • Contact your local Vileda Customer Service (www.vileda.com).
No light when charging	• Charger not fully pushed into main socket. • Charger not fully plugged into charger socket on charger. • Defective main socket or charger.	• Push the charger fully into main socket. • Check charger cord is fully engaged in socket on unit. • Check main socket or charger. Service (www.vileda.com).
Light indicator turns red and blinks slowly	• Battery is low • Use of wrong charger	• Recharge battery for 6 hours • Only use charger as supplied by the manufacturer

For further help, technical advice, or to order spare or replacement parts contact your local Vileda Customer Service (www.vileda.com).

ENVIRONMENTAL AND PRODUCT RECYCLING

This Vileda Wiper, Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances and the management of its disposal. The packaging material is entirely recyclable, and marked with the recycling symbol. Keep the packaging materials (plastic bags, polystyrene parts, etc.) out of the reach of children and animals, as they are potentially dangerous. When the product has reached the end of its life, please so on to dispose of it with general household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. The Vileda Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances must be separated from other waste and submitted to the regime of selective electrical appliances recycling collection. The product contains a Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances. Remove the battery, as official collection points for end-of-life batteries are available. Do not dispose of batteries in fire, as they explode if they are exposed to high temperatures. The violation of these precautions could cause fire and / or serious injuries. For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

DISPOSING OF BATTERY PACK

This appliance contains a Lithium battery which should be removed before disposing of the old appliance. Let the appliance run until the battery is completely empty. Loosen and remove the screws located on the side of the appliance and open the appliance. The appliance may only be opened in order to dispose of the battery pack. Do not short circuit the battery. Remove the battery pack from the appliance and take it to a recycling centre or return it to the application site or the dealer. ⚠ **WARNING:** Do not touch contacts or wires, to prevent risk of short circuit. ⚠ **WARNING:** Battery may explode if exposed to direct sunlight, heat or fire. ⚠ **WARNING:** Opening the battery may lead to risk of injury due to short circuit, chemical burn or escaping irritant vapours.

GUARANTEE INFORMATION

2-YEAR LIMITED GUARANTEE:

GB: Freudenberg Household Products LP, Vileda House, 2 Winchester Street, Rochdale, Lancashire OL16 4AX - DE: FHP Export GmbH, 69448 Weinheim:

As a consumer, you have legal rights in relation to goods that are faulty or not as described. Advice about your legal rights is available from your local Citizens Advice Bureau or Trading Standards Office. Nothing in this guarantee will affect these rights. Nothing in this guarantee is intended to restrict Vileda's liability for death, personal injury or damage to private property caused by the goods proving defective while in the consumer's use as a result of Vileda's negligence. The present guarantee is only valid for the Vileda Wiper Unit, Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances. Vileda guarantees the wiper, motor, will be free of defects due to defective materials or manufacture. If defects arise during the period of guarantee, Vileda will guarantee the replacement of the defective part or provide a new product. **IMPORTANT:** Please keep your purchase receipt! Vileda will repair the wiper, motor, will replace some of its pieces or the entire product only if proof of purchase is provided and the claim is within the period of guarantee. The Vileda Electric Wiper Unit, Motor Lithium Ion Battery, Charger, Cleaning accessories guarantee will automatically come to an end 2 years after the purchase date. The guarantee will be annulled if the product is used in a manner not indicated in the instructions manual, including, as an example, if it has been damaged due to incorrect use or maintenance. 2. If any part is modified or replaced or if it is used in any way other than the intended use, the guarantee will be void. 3. The guarantee does not cover normal wear and tear, consumable parts or accessories. ⚠ **WARNING:** DO NOT USE THE CHARGER FOR ANY OTHER PURPOSE. DO NOT ATTEMPT TO USE THE CHARGER WITH ANY OTHER PRODUCT. NOR ATTEMPT TO CHARGE THE PRODUCT WITH ANOTHER CHARGER. DO NOT DISASSEMBLE THE PRODUCT AND THE BATTERY, AND THEN INVALIDATE YOUR GUARANTEE. ⚠ **WARNING:** To maintain peak performance of the battery it is recommended that the unit is fully discharged and then completely recharged at least once a month.

BATTERY CHARGING & RECHARGING

Vileda Wiper Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances

Dear Customer,

Thank you for purchasing our new Vileda Wiper Motor. Vileda Wiper Motor is a simple-to-use cordless electric wiper designed to dries your windows in seconds. Nothing other than the product will reach your preferred window cleaning liquid. It works like a handvacuum with a rubber lip that presses against your window. It powerfully sucks all dirty water into its integrated reservoir. Thanks to the special 2-mbl rubber lip no drops of water will remain on your window, no streaks on your glass, no cobwebs or even no water droplets left on floor.... Enjoy!

This manual represents a guide for the correct and safe use of the Vileda Wiper Motor. Therefore, you should read all the instructions before using the product for the first time and retain this document for future reference.

CONTENTS:

General Warnings • Unit Parts•Start Up • Instructions • Cleaning the Appliance • Battery Charging & Recharging • Light Indicator • Troubleshooting • Environmental and Product Recycling • Disposing of battery pack • Technical specification • Guarantee information

⚠ IMPORTANT:

READ ALL INSTRUCTIONS BEFORE USE. RETAIN INSTRUCTIONS FOR FUTURE REFERENCE.

HEALTH AND SAFETY WARNINGS:

When using any electrical appliance, basic safety precautions should always be considered in order to reduce the risk of fire, electric shock and personal injuries. Read carefully before using. Follow: • Never immerse unit or charger in water or other liquid • Do not insert objects into the unit • Do not operate appliance if it has been dropped, damaged, left outside or dropped into water, reduced physical, sensory or mental capabilities, lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision • This appliance is supplied at safety extra low voltage. Do not remove the marking on the appliance. • Before using the machine and after any impact, check for signs of wear or damage. • Do not use the appliance if the unit is damaged or faulty. • Do not use the appliance if the charger, cable, plug or switch, or bodyframe the product or charger is any. • Only use the charger supplied with the product. Do not attempt to use the charger with any other product nor attempt to charge this product with another charger. Using an incorrect charger will fire or injure the user and / or the unit. • Before use, check the charger cord for signs of damage or ageing. • Do not attempt to charge a damaged battery. • The appliance contains a rechargeable battery. Do not attempt to remove the battery. Always unplug the appliance before cleaning or maintaining it. • Keep the charger cord away from hot surfaces and sharp edges. • Do not handle the charger with wet hands. • Do not store or charge the unit outdoors. • For further help, technical advice, or to order spare or replacement parts please contact Vileda Customer Service (www.vileda.com).

STORAGE:

• Store in an upright position. • Store in a dry place. • Store out of reach of children. • Ensure appliance is not dropped in during storage.

INTENDED USE:

• Use only as described in this manual. The use of any accessory or attachment or the performance of any operation with this appliance other than those recommended in this instruction manual may present a risk of personal injury. • Use this battery operated appliance only for drying wet, smooth surfaces such as windows, mirrors or tiles. • We don't recommend using the appliance on surfaces that easily scratch, such as wood, steel, varnished and high-gloss surfaces. • Only use this appliance with conventional window cleaners (no spirit, no cleaners that foams). • Do not pick up anything that is flammable, burning or smoking.

START UP

Before you start, remove all protection cartons. When unpacking the product, make sure that no accessories are missing and that none of the package contents have been damaged. If you detect any damages please contact the retailer where you purchased the product. Attach the suction nozzle to the main unit until it snaps in place (Illustration **①**). Charge the battery for 6 hours before first use. (Illustration **②**). (Check section "Battery Charging and Recharging" for more details). After fully charging the unit, the operating time of the appliance is 20 minutes.

INSTRUCTIONS

After you have washed your window with your preferred window cleaning liquid, the Vileda Wendo Matic works like a handvacuum and sucks all dirty water powerfully into its integrated water reservoir. Apply glass cleaner and wipe off. Switch on the appliance, (Illustration **③**). Apply light pressure to the appliance to press squeegee against surface. The correct angle will be adjusted automatically due to the flexible neck of the appliance. Lift the appliance from the top to bottom or horizontally over the surface to vacuum up the detergent. (Illustration **④**). ⚠ **WARNING:** Do not use the appliance on wet surfaces. Do not use the appliance on hot or frozen or very dirty or very hard drinking glass, simply wipe some drops on the surface that needs to be cleaned and pull appliance over fluid. Hard to reach areas can still be reached through the flexible head of the appliance, without loosing contact and therefore suction power to the surface. (Illustration **⑤**).

INTERRUPTING THE WORK

Switch off the appliance and set it down on the pedestal (parking position). (Illustration **⑥**).

CLEANING THE APPLIANCE

Emptying Water Reservoir

Once the max. fill level (100 ml mark) of the dirt water reservoir is reached, please empty it. If the max. level is exceeded, water might get into the ventilation. (Illustration **⑦**). If the appliance is being used with its handle facing down, the dirt water will drip. It is recommended to empty the dirt water reservoir after each window.Turn off the appliance. Push down the release button of the water reservoir and remove the dirt water reservoir from main unit. (Illustration **⑧**). To open water reservoir, apply pressure on imprinted fingertips of the reservoir top and and pull reservoir open. In order to avoid spilling dirt water, don't pull units apart. (Illustration **⑨**). Empty the tank. (Illustration **⑩**).

Cleaning Water Reservoir

For hygienic reasons it is recommended to empty and clean the dirt water reservoir after each use. After taking the water reservoir out of the main unit and opening it, remove tube separator by pulling it out of the water reservoir bottom unit. (Illustration **⑪**). Clean the inside and outside of the water reservoir units under running water or with a cloth. (Illustration **⑫**). ⚠ **WARNING:** Components of the Wendo Vacuum are NOT dishwasher safe! Connect the tube separator back to the water reservoir bottom unit. (Illustration **⑬**). Connect the water reservoir top and bottom unit back together until it is in place. (Illustration **⑭**). Connect the complete water reservoir to the main unit by setting it in place at the bottom part and pushing the top part into the main unit until it snaps in place audibly. (Illustration **⑮**).

STORAGE

Before you start, remove all protection cartons. When unpacking the product, make sure that no accessories are missing and that none of the package contents have been damaged. If you detect any damages please contact the retailer where you purchased the product. Attach the suction nozzle to the main unit until it snaps in place (Illustration **①**). Charge the battery for 6 hours before first use. (Illustration **②**). (Check section "Battery Charging and Recharging" for more details). After fully charging the unit, the operating time of the appliance is 20 minutes.

INSTRUCTIONS

After you have washed your window with your preferred window cleaning liquid, the Vileda Wendo Matic works like a handvacuum and sucks all dirty water powerfully into its integrated water reservoir. Apply glass cleaner and wipe off. Switch on the appliance, (Illustration **③**). Apply light pressure to the appliance to press squeegee against surface. The correct angle will be adjusted automatically due to the flexible neck of the appliance. Lift the appliance from the top to bottom or horizontally over the surface to vacuum up the detergent. (Illustration **④**). ⚠ **WARNING:** Do not use the appliance on wet surfaces. Do not use the appliance on hot or frozen or very dirty or very hard drinking glass, simply wet some drops on the surface that needs to be cleaned and pull appliance over fluid. Hard to reach areas can still be reached through the flexible head of the appliance, without loosing contact and therefore suction power to the surface. (Illustration **⑤**).

INTERRUPTING THE WORK

Switch off the appliance and set it down on the pedestal (parking position). (Illustration **⑥**).

CLEANING THE APPLIANCE

Emptying Water Reservoir

Once the max. fill level (100 ml mark) of the dirt water reservoir is reached, please empty it. If the max. level is exceeded, water might get into the ventilation. (Illustration **⑦**). If the appliance is being used with its handle facing down, the dirt water will drip. It is recommended to empty the dirt water reservoir after each window.Turn off the appliance. Push down the release button of the water reservoir and remove the dirt water reservoir from main unit. (Illustration **⑧**). To open water reservoir, apply pressure on imprinted fingertips of the reservoir top and and pull reservoir open. In order to avoid spilling dirt water, don't pull units apart. (Illustration **⑨**). Empty the tank. (Illustration **⑩**).

Cleaning Water Reservoir

For hygienic reasons it is recommended to empty and clean the dirt water reservoir after each use. After taking the water reservoir out of the main unit and opening it, remove tube separator by pulling it out of the water reservoir bottom unit. (Illustration **⑪**). Clean the inside and outside of the water reservoir units under running water or with a cloth. (Illustration **⑫**). ⚠ **WARNING:** Components of the Wendo Vacuum are NOT dishwasher safe! Connect the tube separator back to the water reservoir bottom unit. (Illustration **⑬**). Connect the water reservoir top and bottom unit back together until it is in place. (Illustration **⑭**). Connect the complete water reservoir to the main unit by setting it in place at the bottom part and pushing the top part into the main unit until it snaps in place audibly. (Illustration **⑮**).

BATTERY CHARGING & RECHARGING

Charge rechargeable for 6 hours before first use. Switch off the unit before charging. Connect the supplied battery charger into the charging socket located below the power buttons. Plug the charger into a suitable electrical socket. The charge/operations display will turn RED when the charger is connected and the battery is charging. The light indicator will turn GREEN after charging is complete. Unplug the charger from the socket and the charger socket. ⚠ **WARNING:** Do not touch contacts or wires, to prevent risk of short circuit. Do not attempt to force to fully recharge the battery pack after the unit is automatically stopped due to low battery power. If the appliance is connected to the charger while it is on, the motor will stop immediately and the battery will start charging. ⚠ **WARNING:** DO NOT USE THE CHARGER WHEN THE CHARGING PORT IS WET IN THE PRODUCT. DO NOT ATTEMPT TO USE THE CHARGER WITH ANY OTHER PRODUCT. NOR ATTEMPT TO CHARGE THE PRODUCT WITH ANOTHER CHARGER. DO NOT DISASSEMBLE THE PRODUCT AND THE BATTERY, AND THEN INVALIDATE YOUR GUARANTEE. ⚠ **WARNING:** To maintain peak performance of the battery it is recommended that the unit is fully discharged and then completely recharged at least once a month.

LIGHT INDICATOR

NO LIGHT (motor running):	Appliance is operating normally
SLOW BLINKING RED (motor running):	Weak battery (equal to less than 20% capacity)
SOLID RED (motor stopped):	Battery is flat
FAST BLINKING RED (motor stopped):	Thermal cut-off activate (e.g. Vent is blocked)
SOLID RED (white charging):	Battery is charging
SOLID GREEN (white charging):	Battery is fully charged
FAST BLINKING RED (white charging):	Detection of damaged battery during charging
SLOW BLINKING RED (white charging):	Detection of wrong charger being plugged in

TROUBLESHOOTING

Problem	Possible reason	Possible solution
Poor cleaning and liquid pick up	• Squeegee is soiled • Nozzle is not completely in contact with surface	• Clean squeegee with a wet cloth. Replace squeegee if necessary. • Ensure the nozzle and the nozzle are connected
Water is leaking from the water reservoir	• The max. fill level (100 ml mark) of the dirt water reservoir is exceeded. • Appliance is being held upside down.	• Empty the dirt water reservoir. • Turn appliance in its upright position.
Cleaning time too short	• Battery flat	• Recharge battery for 6 hours
Unit fails to operate	• Battery flat • Battery is damaged or mechanical defect	• Recharge battery for 6 hours • Contact your local Vileda Customer Service (www.vileda.com).
No light when charging	• Charger not fully pushed into main socket. • Charger not fully plugged into charger socket on charger. • Defective main socket or charger.	• Push the charger fully into main socket. • Check charger cord is fully engaged in socket on unit. • Check main socket or charger. Service (www.vileda.com).
Light indicator turns red and blinks slowly	• Battery is low • Use of wrong charger	• Recharge battery for 6 hours • Only use charger as supplied by the manufacturer

For further help, technical advice, or to order spare or replacement parts contact your local Vileda Customer Service (www.vileda.com).

ENVIRONMENTAL AND PRODUCT RECYCLING

This Vileda Wiper, Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances and the management of its disposal. The packaging material is entirely recyclable, and marked with the recycling symbol. Keep the packaging materials (plastic bags, polystyrene parts, etc.) out of the reach of children and animals, as they are potentially dangerous. When the product has reached the end of its life, please so on to dispose of it with general household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. The Vileda Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances must be separated from other waste and submitted to the regime of selective electrical appliances recycling collection. The product contains a Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances. Remove the battery, as official collection points for end-of-life batteries are available. Do not dispose of batteries in fire, as they explode if they are exposed to high temperatures. The violation of these precautions could cause fire and / or serious injuries. For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

DISPOSING OF BATTERY PACK

This appliance contains a Lithium battery which should be removed before disposing of the old appliance. Let the appliance run until the battery is completely empty. Loosen and remove the screws located on the side of the appliance and open the appliance. The appliance may only be opened in order to dispose of the battery pack. Do not short circuit the battery. Remove the battery pack from the appliance and take it to a recycling centre or return it to the application site or the dealer. ⚠ **WARNING:** Do not touch contacts or wires, to prevent risk of short circuit. ⚠ **WARNING:** Battery may explode if exposed to direct sunlight, heat or fire. ⚠ **WARNING:** Opening the battery may lead to risk of injury due to short circuit, chemical burn or escaping irritant vapours.

GUARANTEE INFORMATION

2-YEAR LIMITED GUARANTEE:

GB: Freudenberg Household Products LP, Vileda House, 2 Winchester Street, Rochdale, Lancashire OL16 4AX - DE: FHP Export GmbH, 69448 Weinheim:

As a consumer, you have legal rights in relation to goods that are faulty or not as described. Advice about your legal rights is available from your local Citizens Advice Bureau or Trading Standards Office. Nothing in this guarantee will affect these rights. Nothing in this guarantee is intended to restrict Vileda's liability for death, personal injury or damage to private property caused by the goods proving defective while in the consumer's use as a result of Vileda's negligence. The present guarantee is only valid for the Vileda Wendo Unit, Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances. Vileda guarantees the wendo matic will be free of defects due to defective materials or manufacture. If defects arise during the period of guarantee, Vileda will guarantee the replacement of the defective part or provide a new product. **IMPORTANT:** Please keep your purchase receipt! Vileda will repair the wendo matic or will replace some of its pieces or the entire product only if proof of purchase is provided and the claim is within the period of guarantee. The Vileda Wendo Unit, Motor Lithium Ion Battery, Charger, Cleaning accessories guarantee will automatically come to an end 2 years after the purchase date. The guarantee will be annulled if the product is used in a manner not indicated in the instructions manual, including, as an example, if it has been damaged due to incorrect use or maintenance. 2. If any part is modified or replaced or if it is used in any way other than the intended use, the guarantee will be void. 3. The guarantee does not cover normal wear and tear, consumable parts or accessories. ⚠ **WARNING:** DO NOT USE THE CHARGER FOR ANY OTHER PURPOSE. DO NOT ATTEMPT TO USE THE CHARGER WITH ANY OTHER PRODUCT. NOR ATTEMPT TO CHARGE THE PRODUCT WITH ANOTHER CHARGER. DO NOT DISASSEMBLE THE PRODUCT AND THE BATTERY, AND THEN INVALIDATE YOUR GUARANTEE. ⚠ **WARNING:** To maintain peak performance of the battery it is recommended that the unit is fully discharged and then completely recharged at least once a month.

BATTERY CHARGING & RECHARGING

Vileda Wendo Unit, Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances

Dear Customer,

Thank you for purchasing our new Vileda Wendo Matic. Vileda Wendo Matic is a simple-to-use cordless electric wiper designed to dries your window in seconds. Nothing other than the product will reach your preferred window cleaning liquid. It works like a handvacuum with a rubber lip that presses against your window. It powerfully sucks all dirty water into its integrated reservoir. Thanks to the special 2-mbl rubber lip no drops of water will remain on your window, no streaks on your glass, no cobwebs or even no water droplets left on floor.... Enjoy!

This manual represents a guide for the correct and safe use of the Vileda Wendo Matic. Therefore, you should read all the instructions before using the product for the first time and retain this document for future reference.

CONTENTS:

General Warnings • Unit Parts•Start Up • Instructions • Cleaning the Appliance • Battery Charging & Recharging • Light Indicator • Troubleshooting • Environmental and Product Recycling • Disposing of battery pack • Technical specification • Guarantee information

⚠ IMPORTANT:

READ ALL INSTRUCTIONS BEFORE USE. RETAIN INSTRUCTIONS FOR FUTURE REFERENCE.

HEALTH AND SAFETY WARNINGS:

When using any electrical appliance, basic safety precautions should always be considered in order to reduce the risk of fire, electric shock and personal injuries. Read carefully before using. Follow: • Never immerse unit or charger in water or other liquid • Do not insert objects into the unit • Do not operate appliance if it has been dropped, damaged, left outside or dropped into water, reduced physical, sensory or mental capabilities, lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision • This appliance is supplied at safety extra low voltage. Do not remove the marking on the appliance. • Before using the machine and after any impact, check for signs of wear or damage. • Do not use the appliance if the unit is damaged or faulty. • Do not use the appliance if the charger, cable, plug or switch, or bodyframe the product or charger is any. • Only use the charger supplied with the product. Do not attempt to use the charger with any other product nor attempt to charge this product with another charger. Using an incorrect charger will fire or injure the user and / or the unit. • Before use, check the charger cord for signs of damage or ageing. • Do not attempt to charge a damaged battery. • The appliance contains a rechargeable battery. Do not attempt to remove the battery. Always unplug the appliance before cleaning or maintaining it. • Keep the charger cord away from hot surfaces and sharp edges. • Do not handle the charger with wet hands. • Do not store or charge the unit outdoors. • For further help, technical advice, or to order spare or replacement parts please contact Vileda Customer Service (www.vileda.com).

STORAGE:

• Store in an upright position. • Store in a dry place. • Store out of reach of children. • Ensure appliance is not dropped in during storage.

INTENDED USE:

• Use only as described in this manual. The use of any accessory or attachment or the performance of any operation with this appliance other than those recommended in this instruction manual may present a risk of personal injury. • Use this battery operated appliance only for drying wet, smooth surfaces such as windows, mirrors or tiles. • We don't recommend using the appliance on surfaces that easily scratch, such as wood, steel, varnished and high-gloss surfaces. • Only use this appliance with conventional window cleaners (no spirit, no cleaners that foams). • Do not pick up anything that is flammable, burning or smoking.

START UP

Before you start, remove all protection cartons. When unpacking the product, make sure that no accessories are missing and that none of the package contents have been damaged. If you detect any damages please contact the retailer where you purchased the product. Attach the suction nozzle to the main unit until it snaps in place (Illustration **①**). Charge the battery for 6 hours before first use. (Illustration **②**). (Check section "Battery Charging and Recharging" for more details). After fully charging the unit, the operating time of the appliance is 20 minutes.

INSTRUCTIONS

After you have washed your window with your preferred window cleaning liquid, the Vileda Wendo Matic works like a handvacuum and sucks all dirty water powerfully into its integrated water reservoir. Apply glass cleaner and wipe off. Switch on the appliance, (Illustration **③**). Apply light pressure to the appliance to press squeegee against surface. The correct angle will be adjusted automatically due to the flexible neck of the appliance. Lift the appliance from the top to bottom or horizontally over the surface to vacuum up the detergent. (Illustration **④**). ⚠ **WARNING:** Do not use the appliance on wet surfaces. Do not use the appliance on hot or frozen or very dirty or very hard drinking glass, simply wet some drops on the surface that needs to be cleaned and pull appliance over fluid. Hard to reach areas can still be reached through the flexible head of the appliance, without loosing contact and therefore suction power to the surface. (Illustration **⑤**).

INTERRUPTING THE WORK

Switch off the appliance and set it down on the pedestal (parking position). (Illustration **⑥**).

CLEANING THE APPLIANCE

Emptying Water Reservoir

Once the max. fill level (100 ml mark) of the dirt water reservoir is reached, please empty it. If the max. level is exceeded, water might get into the ventilation. (Illustration **⑦**). If the appliance is being used with its handle facing down, the dirt water will drip. It is recommended to empty the dirt water reservoir after each window.Turn off the appliance. Push down the release button of the water reservoir and remove the dirt water reservoir from main unit. (Illustration **⑧**). To open water reservoir, apply pressure on imprinted fingertips of the reservoir top and and pull reservoir open. In order to avoid spilling dirt water, don't pull units apart. (Illustration **⑨**). Empty the tank. (Illustration **⑩**).

Cleaning Water Reservoir

For hygienic reasons it is recommended to empty and clean the dirt water reservoir after each use. After taking the water reservoir out of the main unit and opening it, remove tube separator by pulling it out of the water reservoir bottom unit. (Illustration **⑪**). Clean the inside and outside of the water reservoir units under running water or with a cloth. (Illustration **⑫**). ⚠ **WARNING:** Components of the Wendo Vacuum are NOT dishwasher safe! Connect the tube separator back to the water reservoir bottom unit. (Illustration **⑬**). Connect the water reservoir top and bottom unit back together until it is in place. (Illustration **⑭**). Connect the complete water reservoir to the main unit by setting it in place at the bottom part and pushing the top part into the main unit until it snaps in place audibly. (Illustration **⑮**).

BATTERY CHARGING & RECHARGING

Charge rechargeable for 6 hours before first use. Switch off the unit before charging. Connect the supplied battery charger into the charging socket located below the power buttons. Plug the charger into a suitable electrical socket. The charge/operations display will turn RED when the charger is connected and the battery is charging. The light indicator will turn GREEN after charging is complete. Unplug the charger from the socket and the charger socket. ⚠ **WARNING:** Do not touch contacts or wires, to prevent risk of short circuit. Do not attempt to force to fully recharge the battery pack after the unit is automatically stopped due to low battery power. If the appliance is connected to the charger while it is on, the motor will stop immediately and the battery will start charging. ⚠ **WARNING:** DO NOT USE THE CHARGER WHEN THE CHARGING PORT IS WET IN THE PRODUCT. DO NOT ATTEMPT TO USE THE CHARGER WITH ANY OTHER PRODUCT. NOR ATTEMPT TO CHARGE THE PRODUCT WITH ANOTHER CHARGER. DO NOT DISASSEMBLE THE PRODUCT AND THE BATTERY, AND THEN INVALIDATE YOUR GUARANTEE. ⚠ **WARNING:** To maintain peak performance of the battery it is recommended that the unit is fully discharged and then completely recharged at least once a month.

LIGHT INDICATOR

NO LIGHT (motor running):	Appliance is operating normally
SLOW BLINKING RED (motor running):	Weak battery (equal to less than 20% capacity)
SOLID RED (motor stopped):	Battery is flat
FAST BLINKING RED (motor stopped):	Thermal cut-off activate (e.g. Vent is blocked)
SOLID RED (white charging):	Battery is charging
SOLID GREEN (white charging):	Battery is fully charged
FAST BLINKING RED (white charging):	Detection of damaged battery during charging
SLOW BLINKING RED (white charging):	Detection of wrong charger being plugged in

TROUBLESHOOTING

Problem	Possible reason	Possible solution
Poor cleaning and liquid pick up	• Squeegee is soiled • Nozzle is not completely in contact with surface	• Clean squeegee with a wet cloth. Replace squeegee if necessary. • Ensure the nozzle and the nozzle are connected
Water is leaking from the water reservoir	• The max. fill level (100 ml mark) of the dirt water reservoir is exceeded. • Appliance is being held upside down.	• Empty the dirt water reservoir. • Turn appliance in its upright position.
Cleaning time too short	• Battery flat	• Recharge battery for 6 hours
Unit fails to operate	• Battery flat • Battery is damaged or mechanical defect	• Recharge battery for 6 hours • Contact your local Vileda Customer Service (www.vileda.com).
No light when charging	• Charger not fully pushed into main socket. • Charger not fully plugged into charger socket on charger. • Defective main socket or charger.	• Push the charger fully into main socket. • Check charger cord is fully engaged in socket on unit. • Check main socket or charger. Service (www.vileda.com).
Light indicator turns red and blinks slowly	• Battery is low • Use of wrong charger	• Recharge battery for 6 hours • Only use charger as supplied by the manufacturer

For further help, technical advice, or to order spare or replacement parts contact your local Vileda Customer Service (www.vileda.com).

ENVIRONMENTAL AND PRODUCT RECYCLING

This Vileda Wiper, Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances and the management of its disposal. The packaging material is entirely recyclable, and marked with the recycling symbol. Keep the packaging materials (plastic bags, polystyrene parts, etc.) out of the reach of children and animals, as they are potentially dangerous. When the product has reached the end of its life, please so on to dispose of it with general household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. The Vileda Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances must be separated from other waste and submitted to the regime of selective electrical appliances recycling collection. The product contains a Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances. Remove the battery, as official collection points for end-of-life batteries are available. Do not dispose of batteries in fire, as they explode if they are exposed to high temperatures. The violation of these precautions could cause fire and / or serious injuries. For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

DISPOSING OF BATTERY PACK

This appliance contains a Lithium battery which should be removed before disposing of the old appliance. Let the appliance run until the battery is completely empty. Loosen and remove the screws located on the side of the appliance and open the appliance. The appliance may only be opened in order to dispose of the battery pack. Do not short circuit the battery. Remove the battery pack from the appliance and take it to a recycling centre or return it to the application site or the dealer. ⚠ **WARNING:** Do not touch contacts or wires, to prevent risk of short circuit. ⚠ **WARNING:** Battery may explode if exposed to direct sunlight, heat or fire. ⚠ **WARNING:** Opening the battery may lead to risk of injury due to short circuit, chemical burn or escaping irritant vapours.

GUARANTEE INFORMATION

2-YEAR LIMITED GUARANTEE:

GB: Freudenberg Household Products LP, Vileda House, 2 Winchester Street, Rochdale, Lancashire OL16 4AX - DE: FHP Export GmbH, 69448 Weinheim:

As a consumer, you have legal rights in relation to goods that are faulty or not as described. Advice about your legal rights is available from your local Citizens Advice Bureau or Trading Standards Office. Nothing in this guarantee will affect these rights. Nothing in this guarantee is intended to restrict Vileda's liability for death, personal injury or damage to private property caused by the goods proving defective while in the consumer's use as a result of Vileda's negligence. The present guarantee is only valid for the Vileda Wendo Unit, Motor Lithium Ion Battery, Charger, Cleaning accessories and electronic appliances. Vileda guarantees the wendo matic will be free of defects due to defective materials or manufacture. If defects arise during the period of guarantee, Vileda will guarantee the replacement of the defective part or provide a new product. **IMPORTANT:** Please keep your purchase receipt! Vileda will repair the wendo matic or will replace some of its pieces or the entire product only if proof of purchase is provided and the claim is within the period of guarantee. The Vileda Wendo Unit,