

ASSEMBLY INSTRUCTION

1-Put main body of the trolley on floor.



2- Fixing Wringer U metal on the main body. Stright part of U metal must be inside of the body.



3-Insert the Big U METAL



5 - Fixing Big U bars, Press U bar and L bar on the body with screw driver or "L" spanner. Long screws for 2 big U bars and short screw for press U bar.



5-Insert carbage cover into Back U Bar



6- Replace Garbage Cover Supports on the U Metal Bar