

4Ft. Light Drag Harrow



ASSEMBLY AND OPERATION INSTRUCTION

DRAG HARROW



- Lay harrow onto ground and stretch out flat.
- · Rounded heads of carriage bolts on top.
- · Check all fasteners to ensure they are tight.
- Fasten item # 1 quick link onto chain at any desired position to pull harrow straight or at angles.
- Additional weight may be added to unit by placing 8"concrete blocks along front as shown in figure above.
 Hold down straps may be necessary to secure blocks into place.
- After item #1 quick link is in desired position hook link into the hole of your atv's hitch plate.

Item No.	Description	Qty
1	QUICK LINK	1
2	6 ' CHAIN	1
3	3/16" CHAIN CONNECTOR	2
4	HARROW PLATE	4
5	M6 NYLOCK NUT	8
6	FLAT WASHER	8
7	M6 X 35 CARRIAGE BOLT	8
8	4' X 5' X 9-GA. LINK FENCE	1

MAINTENANCE

- 1. At the beginning of each season, using a light machine oil, lubricate the latch, the latch pivot bolt, and the area of the axle where the draw bar tongue pivots.
- 2. Grease or oil the wheel bearings periodically. Use automotive wheel bearing type grease or 20 weight oil.
- 3. Check periodically for loose bolts.
- 4. Keep tire adequately filled. Do not exceed the maximum recommended pressure on tire.